



8. Ensure there is at least **1.5m** from here to the spring attachment point at the stern or fit the spring f'ward using a turning block

7. Ensure this end does not foul any deck equipment when it swings

2. Pierce a hole here with a pencil

4. Position the pencil upright here and use it for the pivot

3. Position this edge Against the cockpit-edge of the Coaming

Pivot Arm

Port side Platform (invert for St'bd side)

6. Swing the template until this edge is parallel to the edge of the coaming

5. Swing the template until this edge is parallel to the edge of the coaming.

1. Cut out the profile around this line

Paper size - A1