



Cut around the profile here

## PIVOT ARM

- 6.** The steering pole fits here.
  - a. For wheel steering position this point just forward, or astern of the wheel, making sure the steering pole will be clear of any obstructions when the platform swings.
  - or
  - b. For tiller steering, this point should be in line with a point on the tiller approximately 8 inches (20cm) from the forward end.

- 1.** Pierce a hole here with a pencil, then position the template on the coaming.
- 2.** Position this edge in line with the cockpit side of the coaming
- 3.** Hold the pencil upright and use it for the pivot
- 4.** Rotate the template until this edge is parallel to the edge of the coaming
- 5.** Rotate the template until this edge is parallel to the edge of the coaming

## STEERSMAN CRUISER TEMPLATE

STARBOARD

(SGC-115)

- 7.** Check there is at least **1.15m** from here to the anchor point for the spring at the stern end.